



## Fixed Tilt Mounting Kit installation Instructions

1. For pipe mounting of antenna. Attach the **antenna(10)** to the **interface brackets (8)** as shown using the provided antenna mounting channel runners.

Adjust the brackets to ensure that they are perpendicular to the antenna and spaced one meter (39-3/8") apart, approx. equal distance from top and bottom of the antenna (use placement guide labels on antenna when provided)

2. Assemble the **pipe grip with elevation(9)** to the **interface brackets(8)** with 3/8" locking hardware.

3. Assemble **rear pipe grip(2)** with one **7"bolt(3)** to the pipe grip with elev. Raise **antenna(10)** to pipe(1). Install second 7"bolt in pipe grip assembly and tighten to pipe. Tighten the 7" bolts to 15Nm (11ft lbs.)

4. Tighten the rest of the 3/8" hardware to 20Nm (15 ft-lbs).

5. Make all electrical connections and weatherproof with self-amalgamating tape.



### PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF JAYBEAM WIRELESS. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF JAYBEAM WIRELESS IS PROHIBITED.

	NAME	DATE
DRAWN	LWH	1-22-06
CHECKED		
ENG APPR.		
MFG APPR.		
Q.A.		

COMMENTS:

DO NOT SCALE DRAWING

## FIXED TILT MOUNTS

SIZE **A** DWG. NO. **MKS02P01 INST** REV. **A**

SHEET 1 OF 1